

## BK1 Quick Operation Guide





|                                   |    |
|-----------------------------------|----|
| Install the Handlebar.....        | 2  |
| Install the Front Fender.....     | 4  |
| Install the Front Wheel.....      | 6  |
| Install the Rear Fender.....      | 8  |
| Install the Pedals.....           | 8  |
| Install the Saddle.....           | 10 |
| Install the Front Reflector.....  | 11 |
| Install the Wheel Reflectors..... | 11 |
| Switch on and off Operation.....  | 12 |

# Parts Introduction



## BK1 parts

1. Saddle/seat post 1 set
2. Pedal 1 pair
3. 16 in 1 tool 1 pcs
4. Bell 1 pcs
5. Front reflector fixing screw 1 set
6. Wheel reflector 2 sets
7. Front reflector 1 pcs
8. Riser screw plug 1 pcs
9. Bowl set dust cover pcs1
10. Front wheel quick release lever 1 pcs
11. Front fender 1 set
12. Front wheel 1 set

# 1.Handlebar installation

1



1. Place the bowl set dust cover on the head tube .



2



2. Insert the handlebar into the frame head tube.  
Note: Do not twist the wires.



Note: The inserted part shall be buried above the safety line (ick mark).

3



3.Pre tighten the screw with the 6mm hex key in the 16 in 1 tool. (Do not tighten it)

4



4. Adjust the handlebar, front fork and frame to be relatively parallel and vertical.

5



5. Tighten the screws with the 6# hex key in the 16 in 1 tool.

6



6. Cover the riser screw plug.

7



7. Rotate clockwise or anticlockwise to adjust the transverse direction to a proper angle.

8



8. Tighten the screw with the 6 # Allen key in the 16 in 1 tool to fix the handle.

## 2. Front fender installation

1



1. Pre install the front light and fender on the front fork with the fixing screw.

2




2. Tighten the screws with the 5# Allen key in the 16 in 1 tool.

3



3. Pre tighten the nut.

4



5



5. Tighten the nut with the assembled tool.

6



6. Use the 4 # Allen key in the 16 in 1 tool to remove the fixing screws of the pre-installed fender support rods on both sides of the front fork.

7



7. Fix the front fender support rod on the corresponding screw hole of the front fork and tighten the screws with the 4 # Allen key in the 16 in 1 tool.



### 3. Front wheel installation

1



1. Loosen the nut in the figure with the 15 # open-end wrench in the 15 in 1 tool and remove the support shaft.

2



2. Clamp the front wheel into the front fork.

Note: Put the disc in to the disc brake.

3



3. Unscrew the quick release rod nut and take out the conical spring.

4



4. Inserting quick release lever.

5



5. Install the conical spring as shown in the figure.

6



6. Screw on the quick release rod nut as shown in the figure.

7



7. Adjust the direction of the handle, adjust the appropriate screw tightness, and tighten the handle upwards.

Note: During this process, ensure that the front wheel is in the center of the front fork tube. If there is deviation, loosen the wrench to adjust the position of the front wheel, and then lock the wrench.

## 4. Rear fender installation



1. Use the 4 # Allen key in the 16 in 1 tool to remove the fixing screws of the pre installed fender support rods on both sides of the frame.



2. Fix the rear fender support rod on the corresponding screw hole of the frame and tighten the screws with the 4 # Allen key in the 16 in 1 tool.

## 5. Pedal installation



The mark "R" on the pedal shaft is right pedal, The sign "L" refers to left pedal.



#### **Installation of right pedal:**

The mark "R" on the pedal shaft is the right pedal. First rotate the pedal shaft clockwise and pre tighten it, enter the crank of the right toothed disc, and then turn clockwise with the 15# open-end wrench to tighten it.



#### **Left pedal installation :**

The mark "L" on the pedal shaft is left pedal. First, rotate the pedal shaft counterclockwise and pre tighten it, enter the crank, and then use the 15# open-end wrench to rotate counterclockwise to tighten it.

## 6.Saddle installation



Pull the quick release lever handle of seat tube in the direction shown in the figure.



Insert the seat tube and adjust it to a proper height (Note: the depth of the seat tube shall be buried above the safety tick mark).



Press the quick release handle in the direction shown in the figure. Note: if the folding wrench is too tight or too loose, please adjust the screw at "1".

## 7. Front reflector installation



Use the cross screwdriver in the 16 in 1 tool to loosen the screw on the front reflector bracket.



Clip the front reflector bracket into the corresponding position of the handlebar, and tighten the screw with the cross screwdriver in the 16 in 1 tool.

## 8. Wheel reflector installation



Clip the wheel reflector into the spoke (note that the spoke should be embedded into the slot in the middle of the wheel reflector).



Turn in the reflector clip, and use the slotted screwdriver in the 16 in 1 tool to tighten it by 90 degrees to fix the wheel reflector.

## 9. Switch on and off Operation



1.Insert the key and turn it to the right from "OFF" to "ON".



2.Power on: press the switch shown in the figure.

1.Insert the key into the hole as shown in Figure 1, and turn the key from "OFF" to "ON".  
2.Press the switch in Figure 2 to switch on. Otherwise, switch off.